

Hours

Day

Minutes

Month

Calendar

Year

Wishes

Lucky Day

52h
AUTONOMY

Your watch's power reserve



Important note: wait 30 seconds after winding the watch before setting the time



Self-winding through your wrist movement



Turning clockwise



Turning counter-clockwise



Turning clockwise until you meet resistance



Turning counter-clockwise until you meet resistance



LOCAL
TIME



2ND TIME
ZONE



High-pitched sound



Low-pitched sound


LADY ARPELS BALLERINE MUSICALE

*MANUAL-WINDING MECHANICAL MOVEMENT
WITH RETROGRADE TIME INDICATION,
ON-DEMAND MUSICAL ANIMATION*


Van Cleef & Arpels

MANUAL-WINDING MECHANICAL MOVEMENT WITH RETROGRADE TIME INDICATION, ON-DEMAND MUSICAL ANIMATION


I. Read the time



II. Wind the watch




III. Set the time



IV. Launch the musical animation

1.



2.

