

Van Cleef & Arpels


Manual-winding quantième de saison mechanical movement

1. Read the time







2. Wind the watch



3. Set the time







Van Cleef & Arpels


Manual-winding quantième de saison mechanical movement

4. Set the date Lady Arpels Heures Filantes





5. Set the time




Van Cleef & Arpels

Pictograms



Your watch's power reserve



Important note: wait 30 seconds after winding the watch before setting the time



Self-winding through your wrist movement



Turning clockwise



Turning counter-clockwise



Turning clockwise until you meet resistance



Turning

counter-clockwise

until you meet

resistance

country



Local time



Time in selected



High-pitched sound



Low-pitched sound